




Werndl™ Emerge™

1.1.2 Height Adjustment


Adjust height using adjusting screw




Clear off top of table.



Adjust the height of each leg in 1 cm increments. Otherwise, there is a danger of twisting the table frame.



Turning the adjusting screw to the right lowers the top of the table to a minimum height of 68 cm.



Turning the adjusting screw to the left raises the top of the table to a maximum height of 76 cm.